

3D Translite Installation (WPC)

Remove glas and translite from your backbox.

Place it face down on a flat surface.



Gently remove the trims.

It won't hurt if you replace the trims with new ones. The plastic may be 2 decades old and has aged. As it got porous, it might break easily.

Remove the original translite and store carefully.



Once removed, you really want to clean the glas from both sides.



Center the 3D translite and flip it over, so that the glas is at the bottom and white side of the translite is up.



Carefully install the top trim by pressing gently along the edge of the glass. The wider side should capture the new translite.



Repeat with lift trim (bottom)



Make sure the translite is centered on the glass.



Install the side trims and put it back into the backbox. Enjoy!

