

10

STEP 10

Repeat on next 2 sides so that only one side is left open. At this point you can add final materials to the box. Remember which side as the bottom of the cabinet. Once additional protection is added perform final inspection. and close final piece.

