

3

STEP 3

Drill pilot holes and then insert Eye Hole Bolt and bolt in place in 4 locations. The eye of the bolt should be located on the inside. Make sure these are tight and that the eye loops you select are fully closed. I preferred to make sure the opening in the loop is facing towards the ground. If it were to open a bit the tension would still be on the strong part.

