

# 11

## STEP 11

Use a step ladder and install the top. Screw to 2x2 cross joints. Tap a few screws at the base to it the bottom base that the pinball sits on. Be careful not to hit the straps. Also use 2.5" screws in the bottom corners on an angle to hit the extended pieces that hold the 2x2 poles.

Congrats you just built Fortknnox.

