

# 9

## STEP 9

Place the first OSB panel that's 38" wide and make sure that the panel is screwed in the corners first to make sure the pallet will be square. Make sure there is a  $\frac{3}{8}$ " space at the top of the panel. Also add the right 2x2 cross piece. Use the 1  $\frac{1}{4}$ " screws.

