

4

STEP 4

Add the piece of OSB to the center of the base. All Eye bolts should be visible and easy to access. Bolt the panel in the marked places. If you are doing option #2. Skip this step and only install base at the end of Step 7.

