



25 VOLT FUSE 15 AMP.	PLAYBOARD LIGHT FUSE 10 AMP.	LIGHTBOX LIGHT FUSE 15 AMP.
--------------------------------------	--	---



2nd CHUTE RELAY	U CONTROL BANK RESET RELAY	E ADD BONUS UNIT RELAY	O OUTHOLE RELAY	P ADD PLAYER UNIT RELAY
------------------------	--	--	------------------------------	---

SB₂ RESET CONTROL RELAY A-1118 COIL	SB₁ RESET CONTROL SWITCHES NO COIL	XB LAST BALL RELAY A-1118 COIL	QB GAME OVER RELAY A-1118 COIL	ZB 1st BALL IN PLAY RELAY A-1118 COIL	PB 2nd PLAYER RELAY A-1118 COIL	LB BONUS VALUE RELAY A-1118 COIL
--	---	--	--	---	---	--

**BANK RESET FUSE
5 AMP. SLO-BLO**

**PRIMARY FUSE
5 AMP. SLO-BLO**

W 3rd CHUTE RELAY

F "E" RELAY DELAY RELAY	S START RELAY	I LEFT HOLE RELAY	T TILT RELAY	J RIGHT HOLE RELAY	H TILT HOLD RELAY	C 50 OR 3000 SCORE RELAY	R HOLD RELAY	D 500 OR 300 SCORE RELAY
---	----------------------------	-----------------------------------	---------------------------	------------------------------------	-----------------------------------	--	---------------------------	--