

**UNIT COIL LOCATIONS**



RELAY BANK RESET	G-1
KNOCKER COIL	G-3
METER	G-3
RELAY RESET	G-3
ADVANCE UNIT RESET	G-3
DROP TARGET COIL	G-4
O-9 DRUM UNIT	G-5
10-90 DRUM UNIT	G-5
1000-9000 DRUM UNIT	G-6
REPLAY STEP-UP	G-7
NO MATCH STEP-UP	G-15
BALL RELEASE COIL	G-15
LARGE BELL	G-16
TOP L BUMPER COIL	G-17
CENTER BUMPER COIL	G-17
BOT L BUMPER COIL	G-17
BOT R BUMPER COIL	G-17
L KICKER COIL	G-18
R KICKER COIL	G-18
ADV. S.U. COIL	G-18
R FLIPPER COIL	G-18
L FLIPPER COIL	G-18

**WIRE COLOR CODE**

1. RED	1. FIRST NO BODY COLOR
2. BLUE	2. SECOND NO. TARGET
3. YELLOW	3. THIRD NO. INDICATE
4. GREEN	4. REUSE OF SAME
5. WHITE	COLOR WIRE
6. BROWN	EXAMPLE
7. DRUMS	10 - RED
8. BLACK	15 - RED-WHITE
9. GREY	30 - GREY
0. NOTKICKER	31 - GREY-RED (USED AGAIN)
J. JUMPER	31 - GREY-RED (USED AGAIN)

**WORD ABBREVIATIONS**

ADJ.	ADJUSTMENT
ADV.	ADVANCE
AMP.	AMPERE
BOT.	BOTTOM
BUT.	BUTTON
C.	CLOSE
D.U.	DRUM UNIT
E.O.S.	END OF STROKE
G.O.	GAME OVER
IMP.	IMPULSE
IND.	INDEX
L.	LEFT
L.T.	LITE
NO.	NUMBER
O.	OPEN
POS.	POSITION
REL.	RELAY
R.O.	ROLL-OVER
R.P.	RELAY
PT.	POINT
S.U.	STEP-UP
SW.	SWITCH
TAR.	TARGET
R.	RIGHT



HEAT WAVE  
 (295)  
 3-5-64 W.D.