

DISPLAY MENU

The first page of the system menu allows you to make adjustments to the game's display.

To change a setting, use **UP/DOWN** to highlight the setting, and press **ENTER** to select it. Press **UP/DOWN** to change the setting. When you are done, press **ENTER** again to save the new setting. Press **SERVICE** advance to the next page and exit the menu.



DISPLAY COLOR

This setting changes the color of the dot matrix display in game. There are several preset color configurations, or you can set it to a custom color.

RED, GREEN, BLUE

0 – 100, Default: GREEN

Turning each of the three colors up or down allows you to set the display to any color you would like.

COLORIZE

ON, OFF, NOT INSTALLED

This setting turns the full colorized display on or off. ON will turn on the fully colorized version. OFF will be the monochromatic game using the DISPLAY COLOR that is set above. If you do not own the color upgrade, this option will be unavailable and marked NOT INSTALLED.

CUSTOM LOGO

Limited and Special Editions of Monster Bash support custom logo display. This requires a microSD card, formatted in FAT32.

Logo Requirements

- Image must be named **userlogo.bmp**
- Image must be **320 x 80 pixels**
- Image must be **24-bit color, uncompressed. This is the normal Windows format for BMPs.**

Custom Logo Instructions

- 1) On your computer, make sure the logo you want to use matches the requirements listed on above.
- 2) Insert a microSD card in your computer. Check that the card is formatted as FAT32.
- 3) Drag and drop the logo onto the top level of the drive (not in a subdirectory). This file must be named userlogo.bmp.
- 4) Remove the card from your computer.
- 5) Remove the backbox insert from Monster Bash.
- 6) With the game powered on, insert the microSD into the controller board. There is only one way the card can be inserted.
- 7) Hold the **SERVICE** button for 5 seconds to enter the CGC System Menu. Press **SERVICE** again to go to the Display Menu.
- 8) Press **START**.

CUSTOM LOGO SETUP

PRESS LAUNCH TO LOAD LOGO FROM SD CARD



PRESS START TO RETURN TO MENU

9) Press **LAUNCH** to load your custom logo, or press **START** to return to the menu.

CUSTOM LOGO SETUP

COMPLETE



USE FLIPPERS TO SELECT IMAGE
PRESS START TO RETURN TO MENU

10) After loading your logo, you will be able select between the Chicago Gaming Company logo or your new custom logo. Use the flippers to switch logos. You can also switch between logos at any time, without a microSD card, by coming back to this menu.

CUSTOM LOGO SETUP

RETURNING TO MENU
PLEASE REMEMBER TO REMOVE SD CARD

GAME WILL NOT BOOT PROPERLY
WITH SD CARD INSTALLED

IF YOU DO NOT REMOVE THE MICROSD CARD AFTER INSTALLING YOUR LOGO, MONSTER BASH WILL NOT BOOT PROPERLY. REMOVE THE CARD AFTER INSTALLING THE LOGO.