


1/4" hex head wood screws – remove and discard. These are installed for shipping purposes to keep the lockdown bar aligned properly. These are not needed once the game is setup.



3/8" nuts attached to carriage bolts – loosen the nuts, adjust the height of lockdown bar receiver, then retighten. Check clearance between shooter rod and auto-launch assembly after lowering the playfield.



Brass screws – adjust height to adjust tightness of the lockdown bar. Adjusting these screws too far will cause clearance issues with the playfield glass.