

ORBITOR PLAYFIELD PARTS LIST

RUBBER RINGS

R1-7A-120-175 R4-7A-120-300
R2-7A-120-200 R5-7A-120-500
R3-7A-120-250 R6-7A-135

PLAYFIELD PLASTIC ASSEMBLIES

A-2161 THRU A-2164
(P1 THRU P4)
C-2156 AND C-2157
(P5 AND P6)
C-2159 AND C-2160
(P7 AND P8)

PLAYFIELD PLASTIC SHIELDS

13C-165-1 THRU -4
(P10 THRU P13)
13C-165-9 THRU 18
(P14 THRU P21)

OTHER PARTS AND ASSEMBLIES

1. 3-Bank Drop Target
D-2140-3-A1 (Left)
2. 3-Bank Drop Targets
D-2140-3-B1 (Right)
4B-195-3Y (Targets Only)
3. 7-Bank Drop Target
D-2184-7A (Top)
4B-195-3B (Targets Only)
4. Stand-up Target Assembly B-2186
5. Stand-up Target Assembly B-2192
6. Flipper Assemblies
B-634-5LY and B-634-5RY
(Lt. and Rt.)
7. Lane Gate Assembly A-2181
8. Spin Target Assembly A-563-4
9. Up-ramp Gate Assembly A-2216
10. Ball Shooter Light Indicator
A-890
11. Screw Cap 4A-463
12. ¼ - 20x½" Flat Hd. Screw
31B-249
13. Screw Cap Washer 3A-213
14. Motor Wheel 7A-147
15. Drive Cleat 1A-2098
16. Retaining Ring 17A-104-37
17. Motor Assemblies C-2152
(Clockwise) or C-2153
(Counterclockwise)
18. Clear Playfield 4D-440
19. Sub-strate 4D-441
20. Marquee 13C-54
21. Light Housing B-2182