



UPPER
RIGHT
FLIPPER

RIGHT
FLIPPER

LEFT
FLIPPER

BLK-YEL

BLU-VIO

BLU-GRY

P/08J3

P/08J3

P/08J3

P/08P3

P/08P3

P/08P3

P/07PI

P/07PI

P/07PI

P/07JI

P/07JI

P/07JI

FLIPPER
BUTTON

FLIPPER
BUTTON

ORG-VIO

ORG-GRY

P/07JI

P/07JI

P/07PI

P/07PI

ORG-VIO

ORG-GRY

IP19

IP19

1

2

SOL. 07 GR

GRY-YEL

6

C-

P/08P4

7 9 8

P/08J4

BLU-YEL

GRY-YEL

E.O.S

E.O.S

E.O.S

.1uf
500V

IP19

IP19