


SWITCHES GALAXY



SWITCHES NOT ON PLAYFIELD:

- | | |
|-----------------|-------------------------|
| 1 *CENTER CHUTE | 7 ROLL-TILT |
| 2 *LEFT CHUTE | 7 PENDULUM |
| 3 *RIGHT CHUTE | 8 TILT BOARD |
| 6 CREDIT BUTTON | 8 DOOR & PLAYFIELD VIB. |

* SEE DRWG. ON SWITCH IDENTIFICATION PAGE