

A-14970 Bookcase Assembly

Item	Part Number	Description	Qty.
1	01-10398	Mounting Bracket	1
2	14-7969	Motor, Bookcase	1
3	01-10399	Switch Bracket	2
4	5647-12693-08	Mini Micro Switch	2
5	5070-09054-00	Diode 1N4004 1.0A	2
6	01-8240	Nut Plate #2-56	2
7	4002-01105-07	MS 2-56 x 7/16 P-PH-S	4
8	4008-01005-10	MS 8-32 x 5/8 P-PH	4
9	03-8619	Crank, Bookcase	1
10	03-8620	Actuator, Bookcase	1
11	4108-01031-14	SMS #8 x 7/8 P-TH-Type 25	2
12	4700-00016-00	FW .187 x .437 x .053	5
13	20-8716-2	Rollpin 3/32 x 5/8	1
14	07-6688-18N	Rivet 3/16 x 1/8 Nickel	4
15	02-4003	Bumper Post 8-32	4
16	23-6535	Rubber Bumper	4
17	03-7655-4	Harness Clip 1/4	2
18	4408-01119-00	Nut 8-32 ESN	5
19	4106-01004-10	SMS #6 x 5/8 P-PH-ST	2
20	A-15018	4 Infra Red LED Assembly	1
21	03-8623	Base, Bookcase	1
22	03-8622	Frame, Bookcase	1
23	03-8621	Cover, Bookcase	1
24	31-1664-25	Screened Playfield Plastic	1
25	H-15229	Cable Assembly, Bookcase	1
26	23-6674	Bumper Pad 1-1/8 x 2-5/16	1
27	07-6688-20N	Rivet 1/4 x 1/8 Nickel	2
28	4700-00003-00	FW .125 x .281 x .032	2
29	03-8624	Lens, Bookcase	4
30	A-15017	4 Opto PCB Assembly	1
31	4106-01004-06	SMS #6 x 3/8 P-PH-ST	2
32	4108-01004-06	SMS #8 x 3/8 P-PH-ST	3
33	02-4419	Adjusting Screw	1
34	02-4418	Shaft, 2-1/2	1
35	03-8347	Gland	1
36	20-9610	Flange Bearing	2
37	03-8363	Locking Nut	1
38	4008-01157-10	MS 8-32 x 5/8 P-PH-S-Ny	1
39	4008-01017-08	MS 8-32 x 1/2 P-PH-S	1
40	H-15227	Bookcase Switch Cable	1
41	4700-00070-00	FW .187 x .625 x .059	2
42	4008-01157-08	MS 8-32 x 1/2 P-PH-S-Ny	1

A-14970 Bookcase Assembly

