





Per engineering regarding the issue with your spinner, and we found that the issue is not with the spinner itself but with the amount of clearance the spinner has on the bracket that houses the spinner.

The remedy is to use a pair of needle-nose pliers and slightly bend the brackets outward in order to allow for extra clearance.

You will need to go into diagnostics, and go to **GAME-SPECIFIC TESTS**, and scroll over to test **#70**. This will drive the “**Electric Magic**” motor up so you can access the assembly.

Please review the images below for further instructions.





Spinner brackets will need to be bent outward, to avoid contact with the spinner. This will give extra clearance to allow the spinner to move freely.

