

FIGURE NO. 7 TARGETS

Item	Part Number	Description
1	54A2822-1	Target Assembly 1 - Rectangle
2	54A2822-2	Target Assembly 2 - Triangle
3	54A2822-3	Target Assembly 3 - Star
4	54A2822-4	Target Assembly 4 - Square
5	54A2822-5	Target Assembly 5 - Circle
6	11R2880	Target Shaft 9" x 1/4" O.D.
7	11R2881	Target Shaft 12" x 1/4" O.D.
8	50S2817	Printed Circuit Board
9	36R2878	Lamp No. 161
10	31R2915	Shaft Fastener
11	21R2825	Phototransistor, FPT 120
12	08R2914	Photo Tran. Light Shield 3/16" I.D.
13	31R2882	Stand Off Fastener

GAME TIME



NUMBER OF GAMES

1 Game For 25¢ 2 Games For 25¢













FIGURE NO. 8 TERMINAL STRIPS

TERMINAL STRIP ASSEMBLIES FIGURE NO. 8

(* All Diodes 1N5059 Unless Noted Other)

Terminal Strip	Item	Part Number	Description
TS-1	*	19R417	Diode, 1N5059
	R3	23R300-315	Resistor, 39 OHM. ½w 10%
	R4	23R300-317	Resistor, 27 OHM. ½w 10%
TS-3, 4, 5 and 6	D9-D13 R7-R12	*	
		23R723-002	Resistor, 180 OHM. 5w
TS-7	D1, D2	*	
	C2	25R515-306	Capacitor, 50 MFD 50v
	R1	23R723-002	Resistor, 100 OHM. ½w 10%
	R2	23R300-324	Resistor, 180 OHM. ½w 10%
TS-8, 9	D14-D18 R14	*	
		23R300-324	Resistor, 180 OHM. ½w 10%
TS-10, 11	D25-D29	*	
TS-12, 13	D30-D34	*	
TS-14, 15 and 16	D3-D5, D19, D20	*	
	OD-1	22R2798	Opto-Isolator
	R15	23R300-326	Resistor, 150 OHM. ½w 10%
	R16	23R2713-001	Resistor, 20 OHM. 20w
TS-17			
TS-18	C8	25R515-208	Capacitor, 1000 MFD 25v
	D35	*	
	R13	19R417	Resistor, 10 OHM. ½w 10%
TP-19	C6	25R515-209	Capacitor, 2000 MFD 25v
	C7	25R986-129	Capacitor, .01 MFD Disc
	D7, D8	*	
TP-20	R5	23R2709-001	Resistor, 301 OHM. ½w 10%
	R6	23R2709-002	Resistor, 332 OHM ½w 10%
	C3 D5	25R974 *	Capacitor, 1 MFD 100v

PARTS NOT PHOTOGRAPHED

CABINET ASSEMBLY

Part Number	Description
11R314	Coin Box Frame
11S2238	Lamp Bracket
11M2613	Fluor. Light Plate
11S2763	Speed Control Arm Bracket
11S2764	Speed Control Switch Bracket
11M2768	Control Arm Bracket
11S2770	Control Arm Switch Plate
11S2831	Molding - T & B
11S2832	Molding - L & R
11S2840	Trim - Center
11R2860	Corner Locks
12S2762	Speed Control Rod
12S2771	Control Rod
20S2303	Timer Motor - 1 RPM
17R2898	Speed Control Switch
17R2854	Limit Switch 2" Lever
17R2899	Credit Switch
07S2843	Control Washer
08S2767	Limit Switch Actuator
08S2769	Control Arm Bushing
14R2587	Speed Control Spring
16R191	Ballast
18R204	Starter Tube Holding
18R205	Tube Holder
18R2267	Cleat Base Socket
36R2781	25w Bulb
11S2382	Timer Cam
01S2900	Shield - Ball Return
31R267	#527 Lock
31R2863	Spacer #8 x 1"
31R2866	Cotter Pin 5/32" x 1-1/2"
31R2905	Credit Switch Mtg. Nut
27R237	Counter
19R417	Diode - 1N5059
25R974	Capacitor - 1 MFD. 100v
07R2906	Ping Pong Ball
15S2887	Cabinet Harness - Jumpers
15S2890	Control Stick Harness - Jumpers
75M2891	Cabinet Harness Layout
75M2894	Control Stick Harness Layout
23R300-324	Resistor 100 OHM. 1/2w 10%
52L2827	Upper Chassis Wood
11S2422A	Connector Bracket
11S2883	Target Bracket