

1-A1	GI Left Orbit Top
1-A2	GI Left Orbit Top Center
1-A3	GI Middle Orbit Center
1-A4	GI Subway
1-A5	GI Left Pop
1-A6	GI Lane Guide Left
1-A7	Top Lane 1
1-A8	GI Lane Guide Middle
1-A9	Top Lane 2
1-A10	GI Right Orbit Top
1-A11	Left Jet 1
1-A12	Left Jet 2
1-A13	Left Jet 3
1-A14	Left Jet 4
1-A15	Left Jet 5
1-A16	Right Jet 1
1-A17	Right Jet 2
1-A18	Right Jet 3
1-A19	Right Jet 4
1-A20	Right Jet 5
1-B1	GI Right Pop 1
1-B2	GI Right Pop 2
1-B3	GI Right Orbit Left
1-B4	Middle Orbit Upper Right
1-B5	GI Scoop Left
1-B6	GI Left Ramp
1-B7	GI Middle Orbit Low Right
1-B8	GI Middle Orbit Middle Right
1-B9	Super
1-B10	Standup 1

1-B11	Standup 2
1-B12	Centre Target Symbol
1-B13	Left Xenomorph Target
1-B14	Right Xenomorph Target
1-B15	Bottom Jet 1
1-B16	Bottom Jet 2
1-B17	Bottom Jet 3
1-B18	Bottom Jet 4
1-B19	Bottom Jet 5
1-B20	GI Left Xenomorph
2-A1	GI Left Revive
2-A2	Weyland
2-A3	Mother
2-A4	Left Eject Symbol
2-A5	Vent 1
2-A6	Left Upper Flipper Lower
2-A7	Left Upper Flipper Higher
2-A8	GI Saucer
2-A9	Left Orbit Arrow
2-A10	Left Orbit Symbol
2-A11	Left Ramp Arrow
2-A12	Left Ramp Drop
2-A13	Bonus 4x
2-A14	Bonus 2x
2-A15	Bonus 6x
2-A16	Double Scoring
2-A17	Vent 2
2-A18	APC 1
2-A19	APC 2
2-A20	APC 3

2-A21	Yutani
2-B1	GI Bank Target Top
2-B2	GI Bank Target Middle
2-B3	GI Bank Target Bottom
2-B4	Side Loop Symbol
2-B5	Standup 5
2-B6	GI Weapon 5
2-B7	Right Orbit Symbol
2-B8	Upper Right Flipper High
2-B9	Right Orbit Arrow
2-B10	Right Upper Flipper Low
2-B11	Right Lane Symbol
2-B12	Standup 4
2-B13	Right Ramp Arrow
2-B14	Right Ramp Drop
2-C1	Host
2-C2	Extra Ball
2-C3	Lock Lit
2-C4	Recharge
2-C5	Recharge Target
2-C6	Centre Ramp Arrow
2-C7	GI Recharge
2-C8	GI Left Orbit Lower
2-C9	GI Left Eject
2-C10	Vent 3
2-C11	Airlock
2-C12	Left Loop Symbol
2-C13	Centre Target Arrow
2-C14	Standup 3
2-C15	GI Weapon Target 4

2-C16	Chestburster Target
2-C17	GI Right Orbit Lower
2-C18	GI Right Flipper Top
3-A1	All Out War
3-A2	Save Newt MB
3-A3	Ambush MB
3-A4	Sentry Guns MB
3-A5	Hypersleep MB
3-A6	Destruct
3-A7	Left Mode 4 (Tunnel Hunt)
3-A8	Left Mode 3 (Find Jonesy)
3-A9	Left Mode 2 (Acid Burn)
3-A10	Left Mode 1 (Derelict Ship)
3-A11	Loader Battle
3-A12	Right Mode 4 (Queens Nest)
3-A13	Right Mode 3 (Bug Hunt)
3-A14	Right Mode 2 (APC)
3-A15	Right Mode 1 (Combat Drop)
3-A16	GI Left Flipper Low
3-A17	Scream
3-A18	GI Left Flipper High
3-A19	Revive Right
3-A20	Revive Left
3-B1	GI Revive Right
3-B2	GI Revive Left
3-B3	GI Right Flipper Low
3-B4	Again
3-B5	GI Right Flipper High
3-B6	Special
3-B7	GI Right Sling Bottom

3-B8	GI Right Sling Top
3-B9	GI Left Sling Bottom
3-B10	GI Left Sling Top
C-X6	Top PF. Lights
C-X7	Backbox Lighting
C-X8	Cab. Side Lights
C-OUT1	Start Button
C-OUT2	BuyIn Button (Extra Ball)
C-OUT3	Launch Buttom (Launch Ball)
C-OUT4	Aux Launch Button
C-OUT5	Coin Door